

Step 1.

Spread the two sides of the Frame (with Display Board) to form a right angle.



Step 2.

Align the six holes of the frame body with the panel. Fasten it afterwards.



Step 3.

Cut the magic tape for about 10cm long and affix it on two plastic tubes.



Step 4.

At the same time, affix the remaining two magic tapes to the back side of the display board following the position of plastic tube.



Step 5.

Complete the assembly by inserting the plastic tube onto the panel.

